

# RESEARCH ABOUT EQUIPOTENTIAL LINES IN ELECTRICITY

Kiana Kamalipoor Shiraz, Farzanegan 2 high school, Tehran, Iran, [kiana.k83@gmail.com](mailto:kiana.k83@gmail.com)

## ABSTRACT

To investigate equipotential lines, two electrodes are inserted into water and particles movement in electric field due to high voltage are illustrated. A supply and a voltmeter are used to determine electric potential at various locations to investigate how equipotential lines deviate from our expectations for different conditions and liquids.

**Keywords:** Equipotential Lines, Liquid, Electric Field

## ARTICLE INFO

Participated in IYPT 2022, Romania  
 Advisor: Dr. Mohammad Shariatmadar  
 Selected by Ariaian Young Innovative  
 Minds Institute, AYIMI  
<http://www.ayimi.org>  
[info@ayimi.org](mailto:info@ayimi.org)

## 1. Introduction

Equipotential lines of each type of electrode are illustrated to find particles movement in electric field due to a high voltage electrodes. Any significant variation in shape of potential lines in different conductivity of different liquids should be considered and theoretical assumptions with experimental data will help to analyze the results.

## 2. Materials and Methods

To observe this phenomenon we have used several liquids such as tap water, water with salt, alcohol and oil and different types of electrode (Fig. 1).



Fig. 1: Types of electrode

When two electrodes are connected to a high voltage (Fig. 2), potential lines are observed which differ in various liquids.




Fig. 2: Electric Potential Lines

Electric Potential lines are shown in macroscopic and microscopic view (Fig. 3).




Fig. 3: Macroscopic and Microscopic view

## 3. Theory

As Poisson's Equation (Eq. 1):

$$\nabla \cdot E = \frac{\rho}{\epsilon_0} \quad E = -\nabla V \quad (1)$$

Therefore potential relates to charge density by Poisson's equation (Eq. 2) which for charge free space it is zero (Eqs. 2 and 3).

$$\nabla^2 V = -\frac{1}{\epsilon} \rho \quad (2)$$

$$\nabla^2 V = 0 \quad (3)$$

The potential of each point (Eqs. 4-6):

$$\psi = \frac{q}{|r - r_0|} + \frac{-q}{|r - r'_0|} \quad (4)$$

$$= \frac{q}{\sqrt{(x-x_0)^2+(y-y_0)^2+(z-z_0)^2}} - \frac{q}{\sqrt{(x-x_0)^2+(y-y_0)^2+(z-z_0)^2}}$$

$$dA = dx dy$$

$$\frac{\partial \psi}{\partial n} = -\frac{\partial \psi}{\partial z} = \frac{-2qz_0}{[(x-x_0)^2+(y-y_0)^2+z_0^2]^{\frac{3}{2}}} \quad (5)$$

$$\Phi_{(r_0)} = \frac{1}{4\pi} \int dx dy \Phi(z=0) \quad (6)$$

and Electric field (Eqs. 7-9):

$$\nabla \times E = 0 \quad \Rightarrow E = -\nabla V \quad (7)$$

but in electro dynamics (Eqs. 8-11):

$$\nabla \times E \neq 0 \tag{8}$$

$$\nabla \cdot B = 0 \tag{9}$$

$$\nabla \times E = \frac{-\partial B}{\partial t} \Rightarrow \nabla \times E = \frac{-\partial (\nabla \times A)}{\partial t} \tag{10}$$

$$\Rightarrow \nabla \times (E + \frac{\partial (\nabla \times A)}{\partial t}) = 0$$

$$\text{so } E = -\nabla V - \frac{\partial A}{\partial t} \tag{11}$$

**Green's Theory:** It states that any two scalar ( $\Phi, \psi$ ) inside a volume (V) having a boundary surface A satisfies the following relationship (Eqs. 12- 13):

$$\int_V dV (\Phi \nabla^2 \psi - \psi \nabla^2 \Phi) = \oint_A dA (\Phi \frac{\partial \psi}{\partial n} - \psi \frac{\partial \Phi}{\partial n}) \tag{12}$$

$$\nabla^2 \psi = -4\pi q \delta^{(3)}(r - r_0) \tag{13}$$

$\delta^{(3)}$  : Delta function in three-dimensional space  
 $\Phi$  : electric potential  
 $\psi$ : auxiliary field

Potential of each point (Eqs. 14-15)

$$\Phi_{(r_0)} = -\frac{1}{4\pi q} \oint_A (\Phi \frac{\partial \psi}{\partial n} - \psi \frac{\partial \Phi}{\partial n}) dA \tag{14}$$

Boundary conditions for  $\Phi$  :

Dirichlet  $\Rightarrow \psi = 0$

Neumann  $\Rightarrow \nabla \psi = 0$

then (Eq. 15):

$$\Phi_{(r_0)} = -\frac{1}{4\pi q} \oint_A \Phi \frac{\partial \psi}{\partial n} dA \tag{15}$$

#### 4. Experiment

In this research we have used linear , point and Concentric electrodes in liquids (Figs. 4-8).



Fig. 4: Experimental setup

point and linear electrodes

Radius of point : 0.2cm  
 Width of plate : 2cm  
 Voltage : 17 v

2V  
 5.5V  
 8V  
 10V  
 12.5V  
 14V




Fig. 5: Potential lines in Point and linear electrodes

Concentric electrodes

Inner radius : 4cm  
 Outer radius : 10cm  
 Width of each : 1 cm  
 Voltage : 17 v

13V  
 9V  
 5V  
 3V




Fig. 6: Potential lines in concentric electrodes

Linear electrodes

Metal plates  
 Width 2 cm  
 Voltage : 17 v

2.5V  
 5V  
 8V  
 11.5V  
 13V





Fig. 7: Potential lines in linear electrodes

point electrodes

Radius 0.2cm  
 Voltage : 17 v

0V  
 8V  
 9V  
 13V





Fig. 8: Potential lines in point electrodes

This experiment is done with various liquids and the results are analyzed (Fig. 9).




Fig. 9: Analysis of experiments in different liquids

By simulation all the results are compared in different electrodes (Figs. 10-13).




Fig.10: Simulation and experiments comparison in linear electrode




Fig.11:Simulation and experiments comparison in point electrode




Fig.12:Simulation and experiments comparison in concentric electrode




Fig.13:Simulation and experiments comparison in linear/ point electrode

## 5. Conclusion

Equipotential lines of each type of electrode were illustrated. There wasn't any significant variation in shape of potential lines in different conductivity of liquids. By changing dielectric constant of liquid potential lines varied. Theoretical expectation and experimental results were compared.

## References

- [1] D.Halliday, In: Fundamentos de Física :eletromagnetismo (LTC, Rio de Janeiro, 2009), v. 3, p. 81
- [2] Griffiths , David j introduction to electrodynamics / David j. Griffiths-3rd-ed
- [3] Feynman, R. P., Leighton, R. B., Sands, M., The Feynman Lectures on Physics, Volume 2, Addison-Wesley, 1977
- [4] Distribution of Charge and Potential in an Electrolyte Bounded by Two Plane Infinite Parallel Plates
- [5] A theoretical method of electric field analysis for dielectrophoretic electrode arrays using green's theorem